

CHRISTEN *

PRODUCT LETTER

No: 000181

CHRISTEN INDUSTRIES, INC.
1048 SANTA ANA VALLEY ROAD
HOLLISTER, CALIFORNIA 95023
TELEPHONE: (408) 637-7405

By: IC Date: 10-16-80 Page: 1 of 1

Send To: 904 FUSELAGE KIT

C-0002

C CHRISTEN INDUSTRIES INC.
U 1048 SANTA ANA VALLEY RD.
S HOLLISTER, CA 95023
T

Subject: INCREASED LENGTH OF
BUSHING WELDED TO VERTI-
CAL FIN FOR ATTACHMENT
OF TAIL WIRE BRACKETS

The length of the bushing which is welded to the front tube of the vertical stabilizer and which is used to attach the front bracewire anchors has been increased. New production fuselages have a 3/4-inch long bushing in place of the original 5/8-inch long bushing.

No modification is necessary for a fuselage structure which has a 5/8-inch long bushing on the vertical stabilizer, except that when the front bracewire anchors are attached as detailed in step B-15 of the 906 construction manual, a 50070-006 washer should be inserted between the bushing and each of the 30916-003 bracewire anchors to space the anchors away from the future fabric covering. A 50067-013 bolt is required in place of the shorter 50067-012 bolt.

Two 50070-006 washers and a 50067-013 bolt are being sent to you by first class mail.

Enclosures:

None