

CHRISTEN \*

PRODUCT LETTER

**AVIAT** inc   
Light Aircraft Manufacturers  
The Airport - Box 1149  
South Washington Street  
Atton, Wyoming 83110

By: LCS

Date: 9-20-95

No: 00374

Page: 1 of 1

Send To: 910 ELECTRICAL KIT

Subject: New Extruded Fiber Washer will replace  
the Original Insulator on Mike Jacks.

C  
U  
S  
T

THE EXTRUDED FIBER WASHER, Waldon P/N: FW-389, will replace the original INSULATOR P/N 31132-001, in all future 910 Electrical Kits.

The 910-M, kit manual will also include the new pages showing the new extruded fiber washer.


The corrected revision pages A-23 thru A-28 and parts list pages PL-3 thru PL-5 should be incorporated into the original manuals and the superceded pages should be discarded.


Listed are the parts and manual pages required for the update.

Enclosures:

- 1 ea page A-23, A-24, A-25, A-26, A-27 and A-28 from 910 Manual
- 1 ea page PL-3, PL-4 and PL-5 of the Parts List from 910 Manual
- 2 ea (80160) EXTRUDED FIBER WASHER, Waldon P/N FW-389

STEP A-11B - Install Regulator on Firewall



PRODUCT SERIES	PRODUCT NAME	<b>CHRISTEN</b> 	
EAGLE AIRCRAFT	ELECTRICAL KIT		
PRODUCT NUMBER	MANUAL SECTION	REVISION	PAGE
910	COMPONENT INSTALLATION	10 7-1-84	A-23

STEP A-12

Install the microphone jack and headphone jack into the right front former:

1. Remove the nut and washer from the 50384-002 microphone jack.
2. If required, file off the anti-rotation tang on the microphone jack at the base of the threaded barrel.
3. Install an 31132-001 insulator onto the microphone jack and place the microphone jack, from the front, into the upper opening in the right front former.
4. Install a 30146-017 plastic washer onto the microphone jack, at the rear of the right front former. Install the washer and nut, removed in step 1, and tighten the nut securely.


CAUTION

The sleeve terminal of the microphone jack must be electrically insulated from ground. Be sure that the plastic insulator and washer installed in steps 3 and 4 above are positioned so as to prevent contact of the jack and the fuselage former.



5. Remove the nut and washer from the 50384-001 headphone jack.
6. Install the headphone jack, from the front, into the lower opening in the right front former.
7. Install the washer and nut, removed in step 5. Tighten the nut securely.


SEE ILLUSTRATION AT RIGHT

STEP COMPLETED ( )

PRODUCT SERIES	PRODUCT NAME		
EAGLE AIRCRAFT	ELECTRICAL KIT		
PRODUCT NUMBER	MANUAL SECTION	REVISION	PAGE
910 -	COMPONENT INSTALLATION	1 6-6-79	A-24

STEP A-12 - Install Jacks in Right Front Former



PRODUCT SERIES <b>EAGLE AIRCRAFT</b>	PRODUCT NAME <b>ELECTRICAL KIT</b>	<b>CHRISTEN</b> 	
PRODUCT NUMBER <b>910</b>	MANUAL SECTION <b>COMPONENT INSTALLATION</b>		
		<b>6-29-79</b>	

STEP A-13

Install microphone jack and headphone jack in the right rear former:

1. Remove the nut and washer from the 50384-002 microphone jack.
2. If required, file off the anti-rotation tang on the microphone jack at the base of the threaded barrel.
3. Install an 31132-001 insulator onto the microphone jack and place the microphone jack, from the front, into the upper opening in the right rear former.
4. Install a 30146-017 plastic washer onto the microphone jack, at the rear of the right rear former. Install the washer and nut, removed in step 1, and tighten the nut securely.


CAUTION

The sleeve terminal of the microphone jack must be electrically insulated from ground. Be sure that the plastic insulator and washer installed in steps 3 and 4 above are positioned so as to prevent contact of the jack and the fuselage former.



5. Remove the nut and washer from the 50384-001 headphone jack.
6. Install the headphone jack, from the front, into the lower opening in the right rear former.
7. Install the washer and nut, removed in step 5. Tighten the nut securely.


SEE ILLUSTRATION AT RIGHT

STEP COMPLETED ( )

PRODUCT SERIES	PRODUCT NAME		
EAGLE AIRCRAFT	ELECTRICAL KIT	REVISION	PAGE
PRODUCT NUMBER	MANUAL SECTION	11 6-15-85	A-26
910	COMPONENT INSTALLATION		

STEP A-13 - Install Jacks in Right Rear Former



PRODUCT SERIES EAGLE AIRCRAFT	PRODUCT NAME ELECTRICAL KIT	<b>CHRISTEN</b> 	
PRODUCT NUMBER 910	MANUAL SECTION COMPONENT INSTALLATION		
		REVISION 2	PAGE 6-29-79 A-27

STEP A-14

Install a 50387-001 terminal board on the outboard side of the front throttle panel. Install a 50315-007 screw and 50070-004 washer, from the inboard side, into each end of the terminal board. Place a 50069-002 nut on each screw and tighten securely.

SEE ILLUSTRATION AT RIGHT

STEP COMPLETED ( )




PRODUCT SERIES	PRODUCT NAME	<b>CHRISTEN</b> 	
EAGLE AIRCRAFT	ELECTRICAL KIT	REVISION	PAGE
PRODUCT NUMBER	MANUAL SECTION	0 8-1-78	A-28
910	COMPONENT INSTALLATION		

FIGURE PL-1 (Page 1 of 5)



PRODUCT SERIES	PRODUCT NAME	<b>CHRISTEN</b> 	
EAGLE AIRCRAFT	INSTRUMENTS KIT		
PRODUCT NUMBER	MANUAL SECTION	REVISION	PAGE
911	PARTS LIST	6 5-15-83	PL-3